

WAT-660D

Operation Manual

This Operation Manual covers safety, camera functions, installation and the correct operating procedure for the WAT-660D. First, we ask you to read this Operation Manual thoroughly, then install and operate the WAT-660D as advised. In addition, for future reference, we also advise safe keeping of this manual.

Please contact the distributor or dealer from which the WAT-660D was purchased, if you do not understand the installation, operation or safety instructions laid out in this manual. Not understanding the contents of the Operation Manual sufficiently may cause damage to the camera.

Guide to the Safety Symbols

The definitions of the symbols used in this operation manual are:

When you do not adhere to or take notice of the "Danger" sign, it may lead to a serious accident such as death or injury caused by fire or electric shock.

When you do not adhere to or take notice of the "Warning" sign, it may cause severe damage such as a physical injury.

When you do not adhere to or take notice of the "Caution" sign, it may incur injury and cause damage to peripheral objects in the immediate surroundings.

Cautions for Safety

WAT-660D is designed to be used safely, however it may lead to a physical accident caused by fire and electric shock if not used correctly. Therefore, please keep and read the "Cautions for Safety" for protection against accidents.

Do not disassemble and/or modify the WAT-660D.
Do not operate the WAT-660D with wet hands.

Use only the AD502-120/230 or equivalent power adaptor for the WAT-660D.

The recommended voltage is DC+9V±10%.

Do not expose the WAT-660D to wetness or high moisture conditions.

The WAT-660D is designed and approved for indoor use only. The WAT-660D is not water-resistant or waterproof. If the location of the camera is outdoors or in an outdoor like environment, we recommend that you use an outdoor camera housing.

Protect the WAT-660D from condensation.
 Keep the WAT-660D dry at all times during storage and operation.

Should the camera not work properly, switch off the power immediately. Then check the camera according to the "Problems and Trouble Shooting" section.

Avoid the striking of hard objects or dropping the WAT-660D.

The WAT-660D uses high quality electrical parts and precision components.

Do not wire the WAT-660D with any monitor using a video/power single transmission terminal. The WAT-660D is not designed for use with this type of equipment. We also advise you to read the operation manual of the monitor you plan to use before any connections are made.

Do not install the WAT-660D in a position subject to direct sunlight.

Sunlight shining directly onto the WAT-660D lens can cause damage to the CCD.

Select a stable place for installation of the WAT-660D.
 Use a support of durable strength around an installation position on a ceiling or wall when a camera stand or tripod is used.

Do not move the WAT-660D with the cables connected.

Before moving the WAT-660D, always remove the video cable and power cable from the rear of the camera first.

Avoid using the WAT-660D near any strong electromagnetic field.

After installing into main equipment, if the WAT-660D is exposed to electromagnetic waves causing the monitored image to become distorted, we recommend the camera be shielded by appropriate protective casing.

Problems and Trouble Shooting

If any of the following problems occur when using the WAT-660D,

- An optimal picture cannot be obtained, after checking that all the cables and connections are correctly in place
- Smoke or any unusual odor emerges from the WAT-660D.
- An object becomes embedded or a quantity of liquid seeps into the camera housing
- More than the recommended voltage or/and amperage has been applied to the WAT-660D by mistake
- Anything unusual occurring to any equipment connected to the WAT-660D.

Disconnect the camera immediately according to the following procedures:

- Switch off the main power supply to the camera.
- Remove the power and video cables connected to the WAT-660D.
- Contact the distributor or dealer from which the WAT-660D was purchased.

About EMC


The WAT-660D is in conformity with EMC test standards carried out by authorized organizations in Japan.

E I A	FCC Part15 class B
CCIR	EN61000-6-3/EN50130-4


Do not modify the WAT-660D. A modified camera may not conform to EMC test standards.

Contents

Using the contents figures below, check to make sure all parts are present before use.



WAT-660D




Cable with connector

Power Supply

If any other power adaptor besides the AD502-120/230 is used, please use a stabilized power adaptor designed for DC+9V±10%, with a current capacity of more than 150mA. Use the optional DC plug if the shape or polarity of the DC plug of the power adaptor to be used is not compatible with the camera.


The wiring on the connector must be exact.

Be careful not to touch the other terminals while wiring. Protect the wired portion by using insulation tape after wiring. If the above care and attention is not adhered to, damage to the WAT-660D and power adaptor may occur and may also cause fire.



Mounting

The WAT-660D has two bosses on both sides featuring M2×2 thread and screws. Use these if the camera is to be mounted to the B001 bracket.




Set-up and Operation

- Refer to the [Power Supply] and the wiring must be exact.
- Join the video out cable with the video in cable of the monitor or peripheral equipment.
- Join the power supply using the correct procedure.
- Make sure that a picture can be seen on the monitor
- To focus, turn the lens clockwise or counterclockwise while observing the picture on the monitor. (Take care when focusing not to scratch or damage the lens.)

Pinhole lenses

Focusing of the pinhole lens (type P3.7) can be done by turning the lens clockwise or counterclockwise while placing a pair of tweezers in the focusing adjustment dents as shown in the figure on the right.



Options

To purchase these options, please contact the distributor or dealer from which you purchased the WAT-660D.



AC Adaptor (AD502-120/230)

The recommended AC adaptor, the WAT-660D for a constant and stable power supply.



Bracket (B001)

B001 is used for mounting the WAT-660D to stands. The base has a U1/4" thread for mounting on stands, and through holes on both sides.



Cable & Connector (660CB)

A cable with BNC, DC jack, connector. The cable length is 30cm.

Specifications

Model	WAT-660D (EIA)	WAT-660D (CCIR)
Pick-up Element	1/4 inch interline transfer CCD image sensor	
Number of Total Pixels	537(H) × 505(V)	537(H) × 597(V)
Number of Effective Pixels	510(H) × 492(V)	500(H) × 582(V)
Unit Cell Size	7.15 μm(H) × 5.55 μm(V)	7.3 μm(H) × 4.7 μm(V)
Sync. System	Internal	
Scanning System	2:1 interlace	
Video Output	Composite video, 1.0 V(p-p) 75Ω (Unbalanced)	
Resolution (H)	More than 400TVL (Center)	
Minimum illumination	0.06 lx. F2.0	
S/N	More than 50dB (AGC=5dB, γ=1.0)	
AE (Auto-exposure)	1/60-1/100000 sec.	1/50-1/100000 sec.
AGC	5-32dB	
Gamma Characteristics	γ ≈ 0.45	
Back Light Compensation	ON	
Power Supply	DC+9V ± 10%	
Power Consumption	0.86W (95mA)	
Operating Temperature	-10 - +40°C (Without condensation)	
Operating Humidity	Less than 95% RH	
Storage Temperature	-30 - +70°C (Without condensation)	
Storage Humidity	Less than 95% RH	
Lens mount	M13 P=1.0	
Standard Lenses	G3.8(Glass f3.8 F2.0) / P3.7(Pinhole f3.7 F4.5)	
Cable Length	300mm	
Size	G3.8: 35.5(W) × 29.5(H) × 29(D) (mm) P3.7: 35.5(W) × 29.5(H) × 15(D) (mm)	
Weight	Approx. 30g (G3.8)	

- Design and specifications are subject to change without notice.
- Watec is not responsible for any inconvenience or the attendant damages to the video and monitoring recording equipment caused by misuse, misoperation or improper wiring of our equipment.
- If for any reason the WAT-660D does not work properly, or if you have any questions regarding installation or operation, please contact the distributor or dealer from which it was purchased.

Contact information



Address: 254-2 Nihonkoku, Daihoji, Tsuruoka-Shi, Yamagata-Ken, 997-0017 Japan
 TEL: +81-235-23-4400 FAX: +81-235-23-4409
 Email: info-o@watec.co.jp
 URL: http://www.watec.net